

# joovy®

## Scooter X2 Instruction Manual 37X Series





# WARNINGS

**Please read this instruction manual completely before using this stroller. Keep these instructions for future reference.**


- Failure to follow these instructions could result in serious injury or death.
- Never leave child unattended.
- Avoid serious injury from falling or sliding out.
- Always use safety belts and ensure that all children are positioned according to these instructions.
- Be certain that the stroller is fully opened, locked securely into position, and the wheel brakes are on before allowing children near the stroller.
- The maximum weight of the child that can be seated in each seat is 45 pounds.
- Use of the stroller with a child weighing more than 45 pounds, or two children totaling more than 90 pounds will cause excessive wear and stress on the stroller and may cause a hazardous unstable condition.
- Never allow a child to step on the footrest to get into or out of the stroller.
- Do not use the stroller on stairways or escalators.
- Keep children away from the stroller when folding or unfolding.
- Hanging purses, shopping bags, parcels, diaper bags or other accessory items from the handlebar or any other parts of the stroller may change the balance of the stroller and cause a hazardous unstable condition.
- The maximum weight that can be carried in the storage basket is 5 pounds. Excessive weight may result in a hazardous unstable condition.
- The total weight that can be placed in the zipper pockets should be less than 2 pounds.
- The total weight that can be placed in the cup holders should be less than 2 pounds.
- Never carry hot beverages or open containers in the cup holders.
- The total weight that can be placed in the in-seat mesh pockets should be less than 2 pounds.
- Never allow your stroller to be used as a toy.
- Discard all packaging materials properly. Do not allow children to play with them.
- Check your stroller for loose rivets, snaps, worn parts, and torn material or stitching on a regular basis.
- Discontinue use of the stroller should it malfunction or become damaged.

**Please do not return this product to the store**

If you experience any difficulty with the assembly or use of this product, or if you have a question regarding these instructions, please contact our Customer Service Department at (877) 456-5049 between the hours of 8:30 am and 5:00 pm Central Time.

**Please note: Styles and colors may vary.**

# Assembling and Using your Stroller

 To ensure safe operation of your stroller, please follow these instructions carefully.

## Unpacking the Product

- Carefully remove stroller and all parts from the box and plastic bag.
- Remove any cardboard packing materials from the stroller.
- Identify the parts (stroller, front wheel set (2), rear wheels (2), rear axle and brake set, canopy, bumper bar, small washers (2), spring washers (2), large washers (4), snap pins (2), hubcaps (2) and documents [not shown]) with the pictures in Figure 1. Also, extra rear wheel assembly parts may be included.
- Remove all cardboard and plastic coverings from any areas of the product. Remove the metal spacer between the hinges and discard.
- Discard all packaging materials properly. Do not allow children to play with them.




Figure 1

## CAUTION

**Adult assembly is required for this product. This package contains small parts. Keep small parts away from children during assembly. No Tools Required.**

## Unfolding the Stroller

- Keep children away from stroller while unfolding.
- Orient the stroller with the handlebar facing upward and closest to you.
- If necessary, release the folding lock located on the right side by lifting the lock off of the extended rivet. See Figure 2.
- Pull upwards on the handlebar until the stroller is completely opened and the latching mechanism on each side is engaged. See Figure 3. NOTE: Be careful not to scratch the floor when opening the stroller.
- Visually check and gently push downward on the handlebar to ensure that the stroller is completely opened and locked before ANY use of the product.




Figure 2




Figure 3

## WARNING

**ALWAYS keep children away from the stroller when unfolding.**

## Installing the Rear Wheel Axle and Brake Set and Rear Wheels

- In a clean, dry place rest the stroller upside down with the rear legs facing upwards.
- Locate the rear axle and brake set and slide it onto the rear legs with the link brake facing the rear of the stroller. Be sure to slide each side all the way on until the push pins are engaged in the holes of the plastic. NOTE: You may need to push each of the push pins in to slide the plastic into place. See Figure 4.
- Pull upward on each side of the rear axle to ensure it is installed properly.
- Push the bar linking the brake levers into the disengaged position. See Figure 5.

### TO INSTALL A REAR WHEEL

- Locate a small washer and slide the washer onto the axle.
- Next place a rear wheel onto the axle over the small washer. NOTE: The brake teeth on the wheel should be facing inward toward the brake lever.
- Then place one large washer onto the axle over the wheel.
- Next slide a spring washer onto the axle.
- Take another large washer and slide it onto the axle.
- Push the washers in to expose the axle hole. Then take one snap pin and insert the straight leg into the small hole in the axle. Push it firmly into this hole until the round portion of the other leg snaps completely around the outside of the axle. NOTE: The snap pin is curved (concave) to make insertion easier.
- Repeat the SAME installation sequence of washers, wheel, and snap pin for the remaining wheel.
- Install a hubcap onto each wheel by aligning the 5 tabs on the hubcap with the 5 slots in the wheel, and then pushing it into place. Ensure that ALL 5 snaps have engaged securely and the hubcap cannot be pulled off.

## Rear Wheel Brakes

- The Scooter comes equipped with a linked rear wheel brake system.
- To engage the rear wheel brakes, push down on one of the brake levers or the bar that connects the levers. See Figure 6.
- The stroller may require slight forward or rearward movement in order to line up the teeth on the brake with each wheel brake cluster.
- Check that the brakes are properly applied by attempting to push the stroller backwards and forwards.
- To release the brakes, gently lift up on one of the brake levers or the bar that connects the levers. See Figure 7.




Figure 4





Figure 5

### REAR WHEEL SEQUENCE






Figure 6




Figure 7

## **WARNING**

**Always make sure the wheel brakes are engaged when the stroller is not being pushed so that the stroller will not roll away. Never leave stroller unattended, especially on a hill or incline, as the stroller may tip over or slide.**

### Installing the Front Wheels

- Orient the stroller so it is resting on the rear wheels and the handlebar. Locate one front wheel set and orient the wheel set with the swivel lock tab facing upward. Insert it onto a plastic post located at the bottom front on one side of the stroller until an audible click is heard. See Figure 8.
- Pull outward on the wheel set to ensure the wheel set is installed properly.
- Repeat this procedure for the other wheel.
- To remove a front wheel set, press the tab at the bottom of the front wheel housing downward and slide the wheel set off of the plastic post. See Figure 9.




Figure 8




Figure 9

### Front Wheel Locks

- The front wheels can be either in swivel mode or locked mode.
- To put each front wheel set into its locked mode, push up on the locking tab located at the top of the wheel housing and between the wheels. Be sure to lift the locking tab all the way up until an audible click is heard. See Figure 10.

NOTE: You may need to rotate the front wheel so the swivel lock tab is facing the front of the stroller.

- To unlock each wheel and put it into swivel mode, push down on the locking tab to disengage the lock.




Figure 10

## Seatback Positioning

Each seatback can be adjusted to any position from fully upright to reclining. The fully upright position should only be used for a child that is at least 6 months old.

- Engage the rear wheel brakes.
- Locate the recline mechanism on the backside of the seat.
- To recline a seat, grasp the buttons on the top and bottom of the recline mechanism and gently pull towards the rear of the stroller until the seat is in the desired position. See Figure 11.
- To adjust a seatback to a more upright position, pull the straps at the end of the recline mechanism rearward while pushing the mechanism forward until the seatback is in the desired position. See Figure 12. Note: To get a seatback into its most upright position you may need to push the seatback toward the front of the stroller before pulling the straps.




Figure 11




Figure 12

## **WARNING**

**ALWAYS** ensure that the seat back is secured into position before placing a child in the seat. Push down on the seatback to be sure it is secure. **NEVER** adjust the seatback when the child is in the seat.

## Adjusting the Leg Supports

The leg support can be adjusted to two positions horizontal or all the way down.

- To place the leg support into the down position, locate the trigger mechanism underneath BOTH sides of the leg support on the bottom. Squeeze BOTH triggers and rotate the leg support down. See Figure 13.

NOTE: The leg support does not “lock” into the down position, but will remain there by gravity only.

- There are fabric flaps that cover the triggers. If necessary, pull each flap over the trigger and attach the Velcro® to secure it.
- To place the leg support into the horizontal position, pull up on both sides of the leg support until it is locked into position. See Figure 14.
- Push down on both sides of the leg support to ensure it is secure.




Figure 13




Figure 14

## **WARNING**

**NEVER** allow a child to step onto or sit on the leg support. This may cause the stroller to tip over and injure the child.

## Installing/Removing the Bumper Bar

- Remove the two safety caps from the frame mount points by pressing the release button and pulling each cap off. See Figure 15.
- Locate the bumper bar and orient it with the male fitting pointed towards the seat unit and the shiny round rivet head facing upward. While holding the male fittings straight, insert the male fittings on the bumper bar into the female fittings located on both sides of the seat. You will hear both sides of the bumper bar “click” in. See Figure 16.
- Pull outward on the bumper bar to ensure it is installed properly and securely.
- To remove the bumper bar, press the buttons located on the underside of both male fittings inward and pull the bumper bar away from the seat. See Figure 17.
- The bumper bar fabric cover can be removed for cleaning. To remove the fabric cover, simply open the zipper on the inside of the fabric cover and pull the cover off of the bumper bar.
- To replace the cover, remove the bumper bar from the stroller, fit the cover over the bumper bar with the zipper facing inward and close the zipper completely.
- When using the stroller without the bumper bar always replace the safety caps.




Figure 15




Figure 16




Figure 17

## **WARNING**

The bumper bar is not a restraint device. Always secure your child with the seat belt. NEVER lift the stroller by the bumper bar. Use caution when attaching the bumper bar when there is a child seated in the stroller.

# Installing, Operating and Removing the Canopy

- Stand behind the stroller with the stroller in the unfolded position.
- Orient the canopy in front of the handlebar with the visor towards the front of the stroller.
- Locate the plastic slide locks on the bottom of each side of the canopy and slide them onto the plastic fitting on each side of the stroller just above the rear leg. See Figure 18.
- Push each side of the canopy firmly down along the fitting until it cannot go any further.
- Fit each rear canopy apron around the back of each seat.
- Attach the Velcro on each canopy apron to the Velcro® on the sides and back of each seat. See Figure 19.
- Attach the Velcro® tabs at the top rear corners of the canopy to the handle tubes just below the handlebar foam. See Figure 20.
- Open the canopy by pulling forward on the front edge.
- The canopy and visor can be adjusted into several positions ranging from fully closed to fully extended, or any position in between. See Figure 21.
- The visor can be opened (or closed) by pulling (or pushing) it from under the canopy.
- Note: The top rear portion of the canopy has a roll back window. To open, pull the forward edge up, roll the flap back and secure it using the elastic loop attachment.
- To close the canopy, push the front edge of the canopy toward the rear of the stroller.
- To remove the canopy, undo the Velcro® attachments on the sides and back of the seat and the handle tubes. Then, slide the canopy up off of both fittings on the sides of the stroller. See Figure 22.




Figure 18




Figure 19




Figure 20




Figure 21




Figure 22



## Securing a Child

NOTE: There are three height adjustment positions for the shoulder harness straps. For a younger child, the shoulder straps should be positioned through the lower sewn-in loops on the seatback. For a young child that is tall, the shoulder straps may be positioned through the upper sewn-in loops on the seatback. For a taller child, use the shoulder straps **WITHOUT** positioning them through these sewn-in loops. To re-position the shoulder straps, unbuckle them from the harness buckle and feed these straps through the sewn-in loops, ensuring that they are not twisted. Re-buckle the shoulder straps onto the harness buckle to secure them.

- Ensure that both shoulder straps are attached to the waist strap buckles. See Figure 23.
- Unlatch the waist/shoulder buckle by squeezing the latch releases on both sides of the buckle and removing the male ends of each buckle. See Figure 24.
- Carefully place the child in the seat with the shoulder straps over their shoulders and chest. Then place the crotch strap between the child's legs.
- Bring the seat belt around the child's waist and insert the male ends of the waist/shoulder buckle into the female buckle. Ensure that they snap into place. See Figure 25. Tighten the waist belt to be snug around the child's waist.
- Both the shoulder straps and the waist/crotch straps may be adjusted using the sliding buckles on these straps. See Figures 26 and 27.

### **WARNING**

**Avoid serious injury from falling or sliding out. Always use the safety harness.**

## Storage Basket

The maximum weight that can be carried in the storage basket is 5 pounds. Excessive weight may result in a hazardous unstable condition.

NOTE: The basket can be removed if desired by unsnapping all of the snaps, opening the zipper in the front and releasing Velcro® straps.




Figure 23




Figure 24




Figure 25




Figure 26




Figure 27

## Folding the Stroller

NOTE: BOTH SEATBACKS MUST BE FULLY RECLINED TO ACHIEVE THE MOST COMPACT FOLD.

- Keep children away from stroller while folding.
- Position the stroller with the handle bars closest to you.
- Engage the rear wheel brakes.
- Close the canopy and push it to the rear of the stroller.
- Recline each seatback downward until it cannot go any further.
- To fold, squeeze the button on the fold mechanism in the center of the handlebar and rotate the mechanism forward until the stroller begins to collapse. Gently rotate the stroller downward until the stroller is fully collapsed. See Figure 28.
- Locate the locking latch near the canopy on the right side of the stroller and rotate the latch until it is engaged on the extended rivet on the rear leg tube. See Figure 29.

CAUTION: While folding the stroller, be careful to keep your fingers from being pinched by moving parts.




Figure 28




Figure 29

## **WARNING**

**ALWAYS** keep children away from the stroller when folding.

## Maintenance

All of the fittings, snaps, locks, rivets, and other hardware and plastic parts on the stroller should be inspected periodically to ensure that they are secured properly and not damaged or malfunctioning. The safety harness, as well as all other straps and fabric items and their stitching should also be inspected periodically to ensure that they are secured properly and not loose, torn or otherwise damaged. All moving parts, such as wheels, brakes, and hinges should also be checked periodically to ensure they are operating properly.

Any missing, broken, or worn components should be replaced immediately, and the stroller should not be used until they are replaced. Only original manufacturer's components should be used. If needed, please contact Joovy at our toll-free phone number.

## Cleaning

The fabric material on this stroller can be cleaned using mild household soap or detergent and warm water on a sponge or clean cloth. Always allow the fabric to completely air dry before using the stroller.

The frame and wheels should always be kept clean and free of dirt and foreign matter, especially after operating the stroller in rain, snow, or other harsh environments. Use a sponge or cloth dampened with warm water and a mild detergent cleaner to clean the wheels after such use.

## SATISFACTION GUARANTEED

We want you to be completely satisfied with your purchase of this product. Should you experience any difficulty in assembling or using this product, or if you have any questions, please contact our Customer Service Department at (877) 456-5049 between the hours of 8:30 am and 5:00 pm Central Time.

Please log onto [www.joovy.com](http://www.joovy.com) to register your new Joovy product.



Free Shipping!  
On Strollers, Toys  
& Playards  
On orders shipped domestically only.



Strollers	Highchairs	Playards	Toys	Accessories	Customer Service	Store
-----------	------------	----------	------	-------------	------------------	-------



©2010 Joovy

Contact: [customerservice@joovy.com](mailto:customerservice@joovy.com)

2919 Canton Street, Dallas, TX 75226

(877)456-5049

Fax: (214)761-1774



Joovy • 2919 Canton Street • (877) 456-5049 • Fax: (214) 761-1774

E-mail: [customerservice@joovy.com](mailto:customerservice@joovy.com) • Web Site: [www.joovy.com](http://www.joovy.com)

©Joovy 2011 • Document Version 021011